

01-153

## Rear window heating, electrical testing

### **Note:**

*Only perform this test on A/C control heads -E87- with only one display (switch for rear window heating is integrated in the A/C control head -E87-).*

### **Special tools and equipment**

- ◆ VAG1715 multimeter (with voltage probe)
- ◆ VAG1594A Measuring Appliance Adapter


### **Test requirements**

- All fuses OK

⇒ *Electrical Wiring Diagrams, Troubleshooting & Component Locations binder*

- Switch ignition off.
- Remove A/C control head -E87- ⇒ [page 87-120](#) .

- Disconnect harness connector E from A/C control head -E87-.



A

- Connect multimeter between terminal 1 and 2 for voltage measurement.


01-154

- Turn ignition on.

Specification: approx. battery voltage

- Switch ignition off.

- Connect harness connector E at A/C control head -E87-.

**A**

- Route wire -A- to harness connector E through current probe on VAG1715.

**Note:**

*All harness connectors at A/C control head -E87- must be connected.*

- Select "Amperage measurement via amperage probe" function on VAG1715 (with voltage probe).

01-155

- Start engine.
  
- Switch rear window heating on via A/C control head -E87- (indicator lamp in button lights up).

Specified value: The display on VAG1715 will change from approx. 0 amps to less than 25 amps.

- Wait approx. 10 minutes.

Specified value: The display on the VAG1715 will change from less than 25 amps to approx. 0 amps (indicator lamp in button goes out).

**Notes:**

- ◆ *The current probe may be influenced by stray current which could cause the display to show a low current reading when rear window heating is switched off.*
  
- ◆ *The A/C control head -E87- will switch rear window heating off after 10 minutes.*
  
- ◆ *When the outside temperature is less than 0° C the heating function of the rear window will remain on until the ignition is switched off (it can*

*be turned off manually at any time). If the temperature while driving exceeds 0° C, the rear window heater is turned off after the operating time stored in -E87- (max. 10 minutes) elapses.*